

INSTALLATION INSTRUCTIONS

FOR


THE W.I.O.E. CONTACT PLUS

AFTER FOLLOWING THE CONTACT INSTALL INSTRUCTIONS WE NOW WILL HOOK UP THE SWITCH.

- STEP 1. RUN THE GROUND WIRE FROM THE DEVICE YOU PLAN TO OPERATE TO THE DOOR POST THAT HAS CONTACTS AND SWITCH INSTALLED. (IF THE UNIT GROUND ITSELF USE THE POWER WIRE)
- STEP 2. STRIP 1/2" OF THE INSULATION AND CRIMP THE RECTANGULAR CONNECTOR ON THE WIRE. SLIDE THE CONNECTOR OVER THE METAL TAB ON THE BACK OF THE CONTACT.
- STEP 3. NOW STRIP 1/2" OF INSULATION FROM ANOTHER WIRE AND CRIMP THE ROUND BULLET CONNECTOR ON IT. PUT THE BULLET CONNECTOR ON THE STUD OF THE SWITCH.
- STEP 4. RUN THE WIRE IN STEP 3 TO A GOOD GROUND. NOTE: IF A POWER WIRE WAS USED INSTEAD OF GROUND RUN THIS WIRE TO A FUSED POWER SOURCE.

THINGS TO REMEMBER

- 1. ALWAYS HAVE THE RIGHT SIZE FUSE FOR THE DEVICE
- 2. THE CONTACT PLUS WITH THE METAL TAB ON THE BACK ALWAYS IS INSTALLED IN THE DOOR POST NOT THE DOOR.
- 3. MAKE SURE THE ADJUSTMENT OF THE CONTACTS MENTIONED IN STEP #4 OF THE W.I.O.E. CONTACT INSTALLATION INSTRUCTIONS IS SET.
- 4. THE EXTRA BULLET CONNECTOR YOU FOUND IS FOR THE DOOR SIDE OF THE SWITCH SO YOU CAN LOCK THIS PLUNGER SO IT WILL NOT VIBRATE OUT ADJUSTMENT.



INSTALLATION INSTRUCTIONS

FOR


THE W.I.O.E. CONTACT PLUS

AFTER FOLLOWING THE CONTACT INSTALL INSTRUCTIONS WE NOW WILL HOOK UP THE SWITCH.

- STEP 1. RUN THE GROUND WIRE FROM THE DEVICE YOU PLAN TO OPERATE TO THE DOOR POST THAT HAS CONTACTS AND SWITCH INSTALLED. (IF THE UNIT GROUND ITSELF USE THE POWER WIRE)
- STEP 2. STRIP 1/2" OF THE INSULATION AND CRIMP THE RECTANGULAR CONNECTOR ON THE WIRE. SLIDE THE CONNECTOR OVER THE METAL TAB ON THE BACK OF THE CONTACT.
- STEP 3. NOW STRIP 1/2" OF INSULATION FROM ANOTHER WIRE AND CRIMP THE ROUND BULLET CONNECTOR ON IT. PUT THE BULLET CONNECTOR ON THE STUD OF THE SWITCH.
- STEP 4. RUN THE WIRE IN STEP 3 TO A GOOD GROUND. NOTE: IF A POWER WIRE WAS USED INSTEAD OF GROUND RUN THIS WIRE TO A FUSED POWER SOURCE.

THINGS TO REMEMBER

- 1. ALWAYS HAVE THE RIGHT SIZE FUSE FOR THE DEVICE
- 2. THE CONTACT PLUS WITH THE METAL TAB ON THE BACK ALWAYS IS INSTALLED IN THE DOOR POST NOT THE DOOR.
- 3. MAKE SURE THE ADJUSTMENT OF THE CONTACTS MENTIONED IN STEP #4 OF THE W.I.O.E. CONTACT INSTALLATION INSTRUCTIONS IS SET.
- 4. THE EXTRA BULLET CONNECTOR YOU FOUND IS FOR THE DOOR SIDE OF THE SWITCH SO YOU CAN LOCK THIS PLUNGER SO IT WILL NOT VIBRATE OUT ADJUSTMENT.



INSTALLATION INSTRUCTIONS

FOR


THE W.I.O.E. CONTACT PLUS

AFTER FOLLOWING THE CONTACT INSTALL INSTRUCTIONS WE NOW WILL HOOK UP THE SWITCH.

- STEP 1. RUN THE GROUND WIRE FROM THE DEVICE YOU PLAN TO OPERATE TO THE DOOR POST THAT HAS CONTACTS AND SWITCH INSTALLED. (IF THE UNIT GROUND ITSELF USE THE POWER WIRE)
- STEP 2. STRIP 1/2" OF THE INSULATION AND CRIMP THE RECTANGULAR CONNECTOR ON THE WIRE. SLIDE THE CONNECTOR OVER THE METAL TAB ON THE BACK OF THE CONTACT.
- STEP 3. NOW STRIP 1/2" OF INSULATION FROM ANOTHER WIRE AND CRIMP THE ROUND BULLET CONNECTOR ON IT. PUT THE BULLET CONNECTOR ON THE STUD OF THE SWITCH.
- STEP 4. RUN THE WIRE IN STEP 3 TO A GOOD GROUND. NOTE: IF A POWER WIRE WAS USED INSTEAD OF GROUND RUN THIS WIRE TO A FUSED POWER SOURCE.

THINGS TO REMEMBER

- 1. ALWAYS HAVE THE RIGHT SIZE FUSE FOR THE DEVICE
- 2. THE CONTACT PLUS WITH THE METAL TAB ON THE BACK ALWAYS IS INSTALLED IN THE DOOR POST NOT THE DOOR.
- 3. MAKE SURE THE ADJUSTMENT OF THE CONTACTS MENTIONED IN STEP #4 OF THE W.I.O.E. CONTACT INSTALLATION INSTRUCTIONS IS SET.
- 4. THE EXTRA BULLET CONNECTOR YOU FOUND IS FOR THE DOOR SIDE OF THE SWITCH SO YOU CAN LOCK THIS PLUNGER SO IT WILL NOT VIBRATE OUT ADJUSTMENT.



INSTALLATION INSTRUCTIONS

FOR

THE W.I.O.E. CONTACT PLUS

AFTER FOLLOWING THE CONTACT INSTALL INSTRUCTIONS WE NOW WILL HOOK UP THE SWITCH.

- STEP 1. RUN THE GROUND WIRE FROM THE DEVICE YOU PLAN TO OPERATE TO THE DOOR POST THAT HAS CONTACTS AND SWITCH INSTALLED. (IF THE UNIT GROUND ITSELF USE THE POWER WIRE)
- STEP 2. STRIP 1/2" OF THE INSULATION AND CRIMP THE RECTANGULAR CONNECTOR ON THE WIRE. SLIDE THE CONNECTOR OVER THE METAL TAB ON THE BACK OF THE CONTACT.
- STEP 3. NOW STRIP 1/2" OF INSULATION FROM ANOTHER WIRE AND CRIMP THE ROUND BULLET CONNECTOR ON IT. PUT THE BULLET CONNECTOR ON THE STUD OF THE SWITCH.
- STEP 4. RUN THE WIRE IN STEP 3 TO A GOOD GROUND. NOTE: IF A POWER WIRE WAS USED INSTEAD OF GROUND RUN THIS WIRE TO A FUSED POWER SOURCE.

THINGS TO REMEMBER

- 1. ALWAYS HAVE THE RIGHT SIZE FUSE FOR THE DEVICE
- 2. THE CONTACT PLUS WITH THE METAL TAB ON THE BACK ALWAYS IS INSTALLED IN THE DOOR POST NOT THE DOOR.
- 3. MAKE SURE THE ADJUSTMENT OF THE CONTACTS MENTIONED IN STEP #4 OF THE W.I.O.E. CONTACT INSTALLATION INSTRUCTIONS IS SET.
- 4. THE EXTRA BULLET CONNECTOR YOU FOUND IS FOR THE DOOR SIDE OF THE SWITCH SO YOU CAN LOCK THIS PLUNGER SO IT WILL NOT VIBRATE OUT ADJUSTMENT.

